

Compressed air container stirrers

Accessories for compressed air container stirrers



FHM heating jacket for 200 L drums

Drum heating jacket for 200 L drums, operating temperature up to 200°C.

Ready-to-use, flexible heating jacket with insulation. Designed for standard 200 litre drums. An optimum heat transfer is guaranteed through flexibility and close fit.

Tension belts and Velcro fasteners allow quick and flexible attachment and removal. The electronic temperature controller heats the product to and/or maintains it at the temperature desired.

Specifications:

Nominal voltage:	230 V a.c.
Nominal power:	see table
Size:	1840 x 880 mm
Cover material:	polyurethane coated fibre-glass
Inner sheath:	silicone coated
Insulation:	felt mat
Heat conductor:	PTFE insulated resistance element with protective layer
Integral temperature sensor:	Pt100
Temperature control:	jacket-mounted
Electronic temperature control:	0 to 200°C
Fastening:	Velcro fasteners and tension belts
Protection class:	I
Protection rating:	IP 65 (spray-proof)
Max. heat conductor temperature:	250°C
Power supply cable:	2 m length with safety plug

An optional temperature limiter may be integrated into the heating circuit.

Applications:

Chemical and petrochemical industry, paint and varnish, resins, adhesives and sealants, disposal of wastes, etc.

Other sizes and models, also for use in hazardous atmospheres, are available on request.

Type	Description	Nominal power	Application	Code-No.
FHM 1	Drum heating jacket	950 Watt	Temperature maintenance	40 26446 00520 7
FHM 2	Drum heating jacket	1500 Watt	Heating	40 26446 00521 4

